



No silicone required.

DURA® Superboot

DESIGNED BY PLUMBERS FOR PLUMBERS



To find out more about this Australian made and owned product simply contact your local Reece Plumbing Centre.

Colour	Code	Size (mm)
Black	1902160	5-60
	1902162	50-100
	1902164	65-130
	1902166	100-170
	1902168	160-240
	1902170	220-320
	1902172	290-420

- no mess
- no fuss
- no silicone

3 easy steps...



2

3

Press firmly into place and
fix to Australian Standards (40mm spacings)